

## 1058.7-CRANE FORK UNIVERSAL LIFTING CAGE

Appearance may vary from picture above.

Designed for the safe transportation of palletized bricks and blocks on both standard and telescopic crane forks. The 1058.7 can be used with crane forks from any manufacturer meaning you can buy just the cage and use your existing forks. The system has major safety benefits over the traditional use of safety nets.

The cage benefits from four internal lifting eyes and can be utilised as a stand alone lifting cage when combined with a suitably rated 4 leg chain.



	Product Code	SWL (kg)	Height (mm)	Width (mm)	Length (mm)	Weight (kg)
External	1058.7	2000	1000	1490*	1685**	545
Internal	1058.7	2000	1190	1225	1480	545

\* inc spreader bar locating pins

\*\* Ramp to gate measurement inc all hinges etc

### NOTES

The following instructions must be read and understood by each intended user of this equipment; if there is anything you do not understand contact Eichinger Equipment Ltd.

Ensure the equipment is adequate for the job you need to carry out.

You must not operate this equipment if you are under the influence of alcohol, drugs or if you are feeling unwell.

A risk assessment should be carried out prior to moving or using this equipment.

The following PPE (Personal protective equipment) should be worn when using this equipment:

Gloves / Goggles / Hard Hat / Steel Toecap boots / Hi-Vis Vest

We also suggest suitable clothing should be worn.

### **Familiarise yourself with the equipment, its use and how it works!**

As this equipment is used at multi-level, ensure the intended area for use is clear of overhead cables and power lines or similar hazards which may affect its safe use. This equipment must always be used in conjunction with your site safety policies.

The work area must be clear of obstructions with adequate space for the operative to work safely around the equipment. Check and ensure the equipment is inspected and in a safe condition prior to its use. Also ensure that its load is stable and secure.



## USING THE EQUIPMENT

Before using this equipment ensure the load is secured to the pallet.

Use the handle to unlatch and open the mesh door ensuring it is clear of the loading area. Set the crane forks to the correct width for the pallet. Position the crane forks fully into the fork pockets of the pallet ensuring the pallet load will be balanced, stable and can be lifted safely.

Position the pallet into the cage ensuring placement is as close to the mesh door as possible, this will ensure maximum stability when lifting.

When the placement of the pallet is correct, remove the crane forks from both the pallet and the cage.

Set the crane forks to the correct width for the fork pockets of the cage ensuring the forks will be equally distanced from the center column of the crane forks.

Position the crane forks fully into the fork pockets of the cage.

Close the mesh door ensuring the locking system is fully engaged, the cage is now ready to be transported to its destination, always ensure the destination is on solid level ground.

We recommend the load is removed from the cage by lowering the ramped door and using a pallet truck to remove the pallet or unloading by hand.

It is possible to open the mesh door and use the crane forks to remove the pallet if the destination allows this procedure to be carried out safely.

## IMPORTANT

**ALWAYS** ensure the pallet load is secured to the pallet.

Ensure the load is not higher than the sides of the cage.

Ensure the crane forks being have sufficient capacity to lift both the load and the weight of the cage.